Fakir
HAUSGERÄTE

PETPARD WF-01 Su Pınarı

Yedek Filtre

Uyumlu Model: Yalnızca PETPARD WF-01 Su Pınarı


Kutu İçeriği: 6 adet su filtresi

UYARI!


Filtreyi kullanmadan önce su dolu bir kap içerisinde yaklaşık 5 dakika bekletiniz. Ardından filtre yuvasına yerleştiriniz.

Filtre Değiştirme Adımları


1- Su çıkış başlığını döndürerek çıkarınız. Ardından paslanmaz çelik tepsiyi kaldırınız.



2- Filtre yuvasında bulunan eski filtreyi çıkarınız ve uygun şekilde atınız.



3- Yeni filtreyi filtre yuvasına yerleştiriniz. Ardından paslanmaz çelik tepsiyi ve su çıkış başlığını tekrar takınız.



NOT!

Su filtresinin her 30 günde bir değiştirilmesi tavsiye edilir.

Fakir
HAUSGERÄTE

PETPARD WF-01 Water Fountain

Replacement Filter

Compatible Model: PETPARD WF-01 Water Fountain only


Box Contents: 6 water filters

WARNING!


Before use, soak the filter in a container filled with water for approximately 5 minutes. Then place it into the filter housing.

Filter Replacement Steps


1- Rotate and remove the water outlet head. Then lift the stainless steel tray.



2- Remove the old filter from the filter slot and dispose of it properly.



3- Insert the new filter into the filter slot. Then reinstall the stainless steel tray and the water outlet head.



NOTE!

It is recommended to replace the water filter every 30 days